

TECHNICAL DATA SHEET

Part#: 530E-US-030

Cutters - Standoff Shear Small Frame - .030" Standoff Reduces shock on delicate components and solder connections

The 530E-US-30 shear action cutter reduces shock on delicate components and solder connections. The "Stand-Off" keeps the cutting blade from cutting into the solder connections. The tip width is .140". Recommended cutting capacity 22 AWG (.025") soft wire. It features an ergonomically molded antimicrobial Anti-Static grip (10¹⁰ ohms/sq surface resistivity) with dual leaf springs.

Precision Level

Material

Carbon

Surface Resistivity

10¹⁰ ohms/sq

Shape

Straight

Type of Cut

Shear

Cutting Capacity

.025"

Blade Angle

.145"

 Blade Length Body Width

0.42" (10.5mm)

• Body Height

OAL

5" (125mm)

• Weight (OZ)

UPC Schedule B

662847013164 8203.20.60.30

• ECCN

EAR99

• UNSPSC Code

27111511

Country of Origin

USA

Group

Small Frame

EXCELTA

530E-US Anti-Shock, Standoff Shear Cutter

A= .650"

B= .115* C= .145







