

TECHNICAL DATA SHEET

Part#: 7270EA

Cutters - Long Nose Fine .03" x .02" Tip - Relieved Head - Short Handle
 Ideal for cutting leads (.020") in a confined space - features a small .200" cutting blade

The 7270EA Lazer Line® small fine tip laser flush cutter has a cutting capacity of .001" - .020" soft wire. It is made of carbon tool steel steel with induction hardened cutting blades to RHC 63-65. This overall length is 5.25". The CNC machining allows the joint surfaces to be perfect to allow for long life. It features a ergonomically molded antimicrobial Anti-Static grip (10¹⁰ ohms/sq surface resistivity) with dual leaf springs.

• Precision Level	★★★★★
• Material	Carbon
• Surface Resistivity	10 ¹⁰ ohms/sq
• Shape	Relieved Head
• Type of Cut	Lazer Flush
• Cutting Capacity	.001" - .020"
• Blade Angle	16°
• Blade Length	.200" (5.08mm)
• Body Width	0.42" (10.5mm)
• Body Height	.250" (6.35mm)
• OAL	5.25" (131.25mm)
• Weight (OZ)	3
• UPC	662847009624
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Long Nose Fine Tip

