

TECHNICAL DATA SHEET

Part#: 9231SL

Cutters - Small Oval Head - Optimum Flush - Slim Line
 High precision cutting where accessibility is critical.

The 9231SL five star Lazer Line® small oval optimum flush cutter has a cutting capacity of .008" - .040" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. It features molded ergonomic antimicrobial Anti-Static grips (10¹⁰ ohms/sq surface resistivity).

• Precision Level	★★★★★
• Material	Carbon
• Surface Resistivity	10 ¹⁰ ohms/sq
• Shape	Oval Head
• Type of Cut	Optimum Flush
• Cutting Capacity	.008 - .040"
• Blade Angle	14.25°
• Blade Length	.250" (6.25mm)
• Body Width	.280" (7.1mm)
• Body Height	.225" (5.7mm)
• OAL	4" (100mm)
• Weight (OZ)	3
• UPC	662847014109
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Small Cutters

