

## TECHNICAL DATA SHEET

Part#: 9238E

**Cutters - Small Taper Relieved Head - Laser Flush**  
 High precision cutting where accessibility is critical.

The 9238E five star Lazer Line® small tapered/relieved laser flush cutter has a cutting capacity of .003" - .025" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. The Anti-Static grips are soft cushioned foam and have a surface resistivity of  $10^{10}$  ohms/sq.

• Precision Level	★★★★★
• Material	Carbon
• Surface Resistivity	$10^{10}$ ohms/sq
• Shape	Tapered/Relieved
• Type of Cut	Laser Flush
• Cutting Capacity	.003" - .025"
• Blade Angle	14.25°
• Blade Length	.25" (6.35mm)
• Body Width	0.32" (8mm)
• Body Height	.225"
• OAL	4.25" (106.25mm)
• Weight (OZ)	3
• UPC	662847013423
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Small Cutters

