

TECHNICAL DATA SHEET



Part#: 9241E-BO

Cutters - Medium Oval Head - Optimum Flush - Black Oxide Coated Designed for cutting .040" soft wire leaving a small 'pinch' on the wire

The 9241E-BO five star Lazer Line® medium oval optimum flush cutter has a cutting capacity of .005" - .040" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The tool has been black-oxide coated to prevent glare and oxidation. The dual leaf springs provide smooth action.

Carbon 10¹⁰ ohms/sq

.005 - .040"

0.42" (10.5mm)

4.5" (112.5mm)

662847013485

8203.20.60.60

14.25°

.25"

3

EAR99

USA

27111511

- Precision Level
- Material
- Surface Resistivity
- Shape Round Head
- Type of Cut Optimum Flush
- Cutting Capacity
- Blade Angle
- Blade Length .31" (7.75mm)
- Body Width
- Body Height
- OAL
- Weight (OZ)
- UPC
- Schedule B
- ECCN
- UNSPSC Code
- Country of Origin
- Group
- Medium Head 9200 Series

MADE IN









