

TECHNICAL DATA SHEET

Part#: 9245SL

Cutters - Medium Taper Head - Laser Flush - Slim Line - Black Oxide Coated
 Designed for cutting .032" soft wire leaving no 'pinch' on the wire

The 9245SL five star Lazer Line® medium tapered laser flush cutter has a cutting capacity of .001" - .032" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. It features molded ergonomic antimicrobial Anti-Static grips (10¹⁰ ohms/sq surface resistivity).

• Precision Level	★★★★
• Material	Carbon
• Surface Resistivity	10 ¹⁰ ohms/sq
• Shape	Taper Head
• Type of Cut	Lazer Flush
• Cutting Capacity	.001" - .032"
• Blade Angle	16°
• Blade Length	.278" (6.95mm)
• Body Width	0.375" (9.38mm)
• Body Height	.225"
• OAL	4.5" (112.5mm)
• Weight (OZ)	3
• UPC	662847014062
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Medium Head - 9200 Series

