

TECHNICAL DATA SHEET

Part#: 9246E

Cutters - Medium Taper Relieved Head - Semi-Flush Designed for maximum tool life, cutting up to .036" diameter soft wire

The 9246E five star Lazer Line® medium tapered/relieved semi-flush cutter has a cutting capacity of .008" - .036" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. The Anti-Static grips are soft cushioned foam and have a surface resistivity of 10¹⁰ ohms/ sq.

 Precision Level Material

Carbon 10¹⁰ ohms/sq Surface Resistivity

Taper Relieved Head Shape Type of Cut Semi-Flush Cutting Capacity .008" - .036" Blade Angle 14.25°

 Blade Length .38" (9.5mm) Body Width 0.42" (10.5mm)

 Body Height .25" 4.5" (112.5mm)

Weight (OZ)

OAL

UPC 662847009884 Schedule B 8203.20.60.60 • ECCN EAR99 • UNSPSC Code 27111511

 Country of Origin USA

Medium Head - 9200 Series Group











