

## TECHNICAL DATA SHEET

Part#: 9246SL

Cutters - Medium Taper Relieved Head -Semi-Flush- Slim Line - Black Oxide Coated

Designed for maximum tool life, cutting up to .036" diameter soft wire

The 9246SL five star Lazer Line<sup>®</sup> medium tapered/relieved semi-flush cutter has a cutting capacity of .008" - .036" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. It features molded ergonomic antimicrobial Anti-Static grips (10<sup>10</sup> ohms/sq surface resistivity).

• Precision Level	★★★★
• Material	Carbon
• Surface Resistivity	10 <sup>10</sup> ohms/sq
• Shape	Taper Relieved Head
• Type of Cut	Semi-Flush
• Cutting Capacity	.008" - .036"
• Blade Angle	16°
• Blade Length	.278" (6.95mm)
• Body Width	0.375" (9.38mm)
• Body Height	.225"
• OAL	4.5" (112.5mm)
• Weight (OZ)	3
• UPC	662847014079
• Schedule B	8203.20.60.60
• ECCN	EAR99
• UNSPSC Code	27111511
• Country of Origin	USA
• Group	Medium Head - 9200 Series

