

TECHNICAL DATA SHEET

Part#: 9250SL

Cutters - Large Oval Head - Semi-Flush - Slim Line - Black Oxide Coated
Designed for cutting .060" soft wire

The Slim Line 9250SL Lazer Line® large oval semi-flush cutter has a cutting capacity of .008" - .060" soft wire. It is made of carbon tool steel with induction hardened cutting blades to RHC 63-65. The CNC machining allows the joint surfaces to be perfect to allow for long life. The dual leaf springs provide smooth action. It features molded ergonomic antimicrobial Anti-Static grips (10¹⁰ ohms/sq surface resistivity).

- Precision Level ★★★★★
- Material Carbon
- Surface Resistivity 10¹⁰ ohms/s
- Shape Oval Head
- Type of Cut Semi-Flush
- Cutting Capacity .008" - .060"
- Blade Angle 14.25°
- Blade Length .430" (10mm)
- Body Width 0.5" (12.5mm)
- Body Height .225" (5.63mm)
- OAL 4.5" (112.5mm)
- Weight (OZ) 3
- UPC 662847015502
- Schedule B 8203.20.60.60
- ECCN EAR99
- UNSPSC Code 27111511
- Country of Origin USA
- Group Large Head

